

# EG4<sup>®</sup> MONITOR CENTER

## OVERVIEW

The EG4<sup>®</sup> Monitor Center has new features that allow the end user to easily check real-time system information regarding inverters, batteries, and other informative values. The images and descriptions in this guide will provide an overview of the EG4 Monitor Center, its settings and what they entail.




**TABLE OF CONTENTS**

1.	MONITOR CENTER OVERVIEW .....	1
2.	MONITOR TAB .....	4
2.1	SOLAR YIELD.....	4
2.2	BATTERY DISCHARGE/CHARGE.....	5
2.3	FEED-IN ENERGY/IMPORT .....	5
2.4	CONSUMPTION.....	5
2.5	SYSTEM INFORMATION.....	6
2.6	WEATHER FORECAST .....	7
2.7	EXTENDED SYSTEM INFORMATION.....	8
2.8	BATTERY INFORMATION.....	9
2.9	INPUT & OUTPUT POWER .....	10
2.10	ENERGY OVERVIEW .....	10
3.	DATA TAB .....	11
3.1	CHART .....	11
3.2	CHART COMPARE.....	11
3.3	ENERGY.....	13
3.4	DATA HISTORY .....	14
3.5	LOCAL DATA.....	14
3.6	EVENT HISTORY .....	15
4.	CONFIGURATION TAB.....	15
4.1	STATIONS.....	15
4.2	DONGLES.....	16
4.3	DEVICES.....	16
4.4	USERS .....	16
4.5	USER MIGRATION RECORD .....	17
5.	OVERVIEW TAB.....	17
5.1	STATION OVERVIEW .....	17
5.2	DEVICE OVERVIEW.....	17
6.	MAINTENANCE TAB.....	18
6.1	REMOTE SET .....	18
6.2	WORKING MODE SETTINGS PAGE .....	27
6.3	SET RECORD.....	43
6.4	WEATHER OPTIMIZE .....	43
6.5	REMOTE UPDATE.....	45
6.6	UPDATE RECORD.....	45
7.	CHANGELOG .....	46

## 1. MONITOR CENTER OVERVIEW


The EG4® Monitor Center is a cloud-based software that is accessible using a web browser. Begin by navigating to the EG4 Monitor Center website and signing in.






## NOTE:

Certain features shown in this guide are only available on select EG4® inverter models and certain tiers of customer account access.



Once signed in to the Monitor Center, the user is placed on the default landing page. This page is referred to as the “Monitor” tab. Located at the top of the Monitor Center page, there are 5 tabs that can be selected.


- A. Monitor** – The “Monitor” tab displays Solar Yield, Battery Discharge/Charge, Feed-In Energy/Import, Consumption, real time System Information and Weather Forecast.
- B. Data** – The “Data” tab contains detailed charts and data for inverters, solar arrays (if applicable) and batteries. This tab also has 6 pages.
  - **Chart** – Displays various parameters in chart format over a 24-hour period. There are separate charts for “PV Side,” “Battery,” “AC Side,” “Backup Output,” “Gen Side,” and “Internal Sample.”
  - **Chart Compare** – Allows comparison of parameters in chart format over a 24-hour period. Separate comparison charts are available for “PV Side,” “Battery,” “AC Side,” “Backup Output,” “Gen Side,” and “Internal Sample”.
  - **Energy** – Displays how key energy parameters have varied over time.
  - **Data History** – Displays the measured technical values of PV, battery, load, and grid for users or their distributor's examination to promptly address any potential issues.
  - **Local Data** – The data captured during the offline periods are displayed in the "Local data" section (loss of internet or Wi-Fi).
  - **Event History** – The "Event History" section displays a timeline of Notice and Fault events.



## NOTE:


The “Data” tab will only display information on solar arrays when using Tigo Optimizers.

- C. Configuration** – The “Configuration” tab is designated for users to manage their station, dongle, and user information. This tab has 5 pages.
  - **Stations** – The “Stations” section will show all stations linked to the account. Selecting a station name will display all inverters under that station or location.
  - **Dongles** – Users can add the dongle Serial Number (SN) in the station if they have more than one inverter in the station.
  - **Devices** – Users can view the general data for each of the inverters tied to the user’s account.
  - **Users** – This page shows a full list of users, distributors, and any other roles linked to the account.
  - **User Migration Record** – This page tracks changes made to user accounts, including the transfer of end users and dongles.




**D. Overview** – The "Overview" tab allows EG4® or its distributors to quickly monitor system-wide data for their end users, such as solar yields, battery discharging, and other factors. This tab will have 2 pages.

- **Station Overview** – All stations linked to the account can be found here.
- **Device Overview** – All inverters linked to the account can be found here.



**E. Maintenance** – The "Maintenance" tab allows the end user to set up and update their system. This tab will have 6 pages.

- **Remote Set** – This page will allow end users to set up their system for their specifications and uses.
- **Set Record** – This page will show the end user a history of what has been done to the system, past or present.
- **Weather Optimize** – This page will allow the end user to set up their system for the best results according to weather conditions.
- **Remote Update** – This page shows all firmware updates for the system, past or present.
- **Update Record** – This page will show the end user a record of all updates for the system, past or present.



To access more on the "Data", "Configuration", "Overview", and "Maintenance" tabs, navigate to the corresponding sections in this document. This provides the end user more information of what each tab does and the information within each subpage.


## 2. MONITOR TAB

After logging in to the EG4® Monitor Center and setting up the station, confirm that the correct inverter station has been selected. The default selection upon logging in will take the end user to the “Monitor” tab, showing real time System Information, with tabs across the top of the screen. *See image below.*



### NOTE:


Certain features shown in this guide are only available on select EG4® inverter models and certain tiers of account access.




### 2.1 SOLAR YIELD

The data in this section shows power generated by the solar array. AC coupled inverters will display the power generated by the grid-tied inverter. To accurately show data, the PV CT clamp for the AC ESS inverter will have to be installed. When the “Solar Yield” image is selected, the area displays the amount of solar energy used that day and a second mouse click displays the total Solar Yield since commissioning the system (*see images below*). Solar Yield data also includes the percentage portion of load supplied, total charge of battery, and total energy exported.

#### Daily usage





#### Total since commissioning





## 2.2 BATTERY DISCHARGE/CHARGE

The data in this section shows the charge and discharge of energy from the battery bank. When the battery picture is selected, the display will switch between Battery Discharge and Battery Charge showing totals for that day and since commissioning.




## 2.3 FEED-IN ENERGY/IMPORT

Displays energy exported to grid for that day and since commissioning. When the image is selected, it shows energy imported from the grid for that day and since commissioning.




## 2.4 CONSUMPTION

The data in this section displays the total energy consumption of the location for that day and since commissioning.



## 2.5 SYSTEM INFORMATION

The image below displays live energy data with dynamic flows.




**A. Battery Information** – When the battery image is selected, the display will show battery charge and discharge limitations. The battery image color represents the following: Green = Healthy, Yellow = Warning, Red = Fault.

**B. Solar Yield** – The data will show the watts and volts that each array in the system is producing.

**C. Status** – The end user can see what state their inverter is in.

- **Grey color:** Inverter is offline and will stop power input and output.
- **Green color:** Inverter is functioning properly.
- **Orange color:** Inverter has experienced an event with a level of Notice or Warning. See note below.
- **Red color:** Inverter has a fault.



### NOTE:

Selecting the “Notice” event type will display the event(s) within the Data Tab under Event History (see image below).

Station	Serial number	Event Type	Event	Start Time	Time Recovered
1		Notice	W007: LCD communication fault	2025/10/02 08:38:55	
2		Notice	W007: LCD communication fault	2025/10/01 16:28:21	2025/10/02 08:26:51
3		Notice	W000: Communication failure with battery	2025/10/01 16:20:19	2025/10/02 08:26:51
4		Notice	W000: Communication failure with battery	2025/10/01 14:51:47	2025/10/01 14:59:51
5		Notice	W007: LCD communication fault	2025/10/01 14:43:43	2025/10/01 16:16:16
6		Notice	W000: Communication failure with battery	2025/10/01 14:31:37	2025/10/01 14:35:39
7		Notice	W000: Communication failure with battery	2025/10/01 14:03:24	2025/10/01 14:25:33
8		Notice	W027: Battery open	2025/10/01 13:59:22	2025/10/02 08:38:55



## NOTE:

Selecting the “Fault” event type will display the event(s) within the Data Tab under Event History (see image below).

Station	Serial number	Event Type	Event	Start Time	Time Recovered
1		Notice	W027: Battery open	2024/05/09 13:11:52	2024/05/09 13:12:38
2		Fault	E019: Bus voltage high	2024/05/07 11:18:25	2024/05/07 11:19:25
3		Fault	E019: Bus voltage high	2024/05/07 11:05:26	2024/05/07 11:08:26
4		Notice	W025: Battery voltage high	2024/05/05 18:15:44	2024/05/05 18:16:45
5		Notice	W025: Battery voltage high	2024/05/04 10:17:41	2024/05/04 10:18:43
6		Notice	W025: Battery voltage high	2024/05/03 17:33:16	2024/05/03 17:34:17
7		Notice	W028: EPS Over load	2024/05/02 10:55:15	2024/05/02 10:56:15
8		Notice	W000: Communication failure with battery	2024/05/02 09:46:21	2024/05/02 09:47:22

**EPS** – The system converts power from battery/solar to AC line 1 and 2. EPS L1N and L2N will display the amount of watts consumed on each line.

**D. Utility/Grid** – Displays the grid input is present.

**E. Consumption Power** – When the inverter is running in bypass mode, this value shows the power being pulled from the grid.

**F. Start Functions** – Three start options for Gen Quick Start, Start Quick Charge and GEN Runtime.

- **GEN Quick Start** – Starts generator automatically for regular upkeep and to ensure it is functioning properly. Runs for 20 minutes and follows the logic setup by the system in regard to the generator.
- **Start Quick Charge** – Takes AC power for one hour and diverts it to charge batteries while putting the inverter in Bypass Mode.
- **GEN Runtime** – Tracks how long the generator has been operating for.

## 2.6 WEATHER FORECAST

The image below shows the weather forecast. See callout 6 on Page 4 for full screen.

✕

Save

**Weather Forecast**


Get weather updates and our AI Solar Generation Forecast by adding your location. Stay ahead of bad weather and optimize your energy use with smart insights.

Add Location

- **Add Location:** To see what the weather will be like for the end users location.
- **Save:** After adding location, this will save for future reference.

## 2.7 EXTENDED SYSTEM INFORMATION

The image below shows additional battery information. See callout 7 on Page 4 for full screen.



- **Remain Cap:** Remaining Ah capacity in the battery.
- **Full Cap:** Remaining Ah capacity in the full bank.
- **Total Battery:** The number of batteries.
- **Discharge Current:** Total discharge for all batteries.
- **Total Voltage:** Total voltage for entire bank.

## 2.8 BATTERY INFORMATION

Next, scroll down the “Monitor” tab and this section will show the number of batteries an end user has on their system. Here the end user will be able to see additional values of the battery bank.

Battery Information <input type="checkbox"/> Show all parameters		Battery 1 - EG4_485-1_ID03 - V 0.00		Battery 2 - EG4_485-1_ID05 - V 0.00		Battery 3 - EG4_485-1_ID06 - V 3.37	
<b>52.28 V</b> Total Vol	<b>78 %</b> SOC	<b>52.29 V</b> Total Vol	<b>80 %</b> SOC	<b>52.3 V</b> Total Vol	<b>82 %</b> SOC	<b>52.33 V</b> Total Vol	<b>79 %</b> SOC
<b>-48.9 A</b> Current	<b>100 %</b> SOH	<b>-43.9 A</b> Current	<b>100 %</b> SOH	<b>-39.2 A</b> Current	<b>0 %</b> SOH	<b>-44.7 A</b> Current	<b>98 %</b> SOH

- **Battery ID** – The name of the battery.
- **Total Voltage** – Total voltage of the battery.
- **SOC** – The state of charge of the battery.
- **Current** – The charge/discharge current of the battery.
- **SOH** – State of health of the battery.

**Show all parameters:** Select the check box to display additional details about the battery.

Battery Information  Show all parameters

Battery Information  Show all parameters

Battery Information <input checked="" type="checkbox"/> Show all parameters		Battery 1 - EG4_485-1_ID03 - V 0.00		Battery 2 - EG4_485-1_ID04 - V 0.00		Battery 3 - EG4_485-1_ID05 - V 0.00	
<b>51.45 V</b> Total Vol	<b>33 %</b> SOC	<b>51.47 V</b> Total Vol	<b>38 %</b> SOC	<b>51.47 V</b> Total Vol	<b>46 %</b> SOC	<b>51.5 V</b> Total Vol	<b>43 %</b> SOC
<b>-43.5 A</b> Current	<b>100 %</b> SOH	<b>-42.1 A</b> Current	<b>100 %</b> SOH	<b>-37.8 A</b> Current	<b>0 %</b> SOH	<b>-40 A</b> Current	<b>0 %</b> SOH
<b>29 °C</b> Min Temp / Cell 0	<b>29 °C</b> Max Temp / Cell 0	<b>28 °C</b> Min Temp / Cell 0	<b>29 °C</b> Max Temp / Cell 0	<b>25 °C</b> Min Temp / Cell 0	<b>25 °C</b> Max Temp / Cell 0	<b>26 °C</b> Min Temp / Cell 0	<b>26 °C</b> Max Temp / Cell 0
<b>3.213 V</b> Min Volt / Cell 3	<b>3.218 V</b> Max Volt / Cell 4	<b>3.215 V</b> Min Volt / Cell 6	<b>3.219 V</b> Max Volt / Cell 10	<b>3.18 V</b> Min Volt / Cell 0	<b>3.228 V</b> Max Volt / Cell 0	<b>3.216 V</b> Min Volt / Cell 0	<b>3.222 V</b> Max Volt / Cell 0
<b>353</b> Cycle Count		<b>143</b> Cycle Count		<b>0</b> Cycle Count		<b>0</b> Cycle Count	

- **Min. Temp** – The cell number with the lowest temperature.
- **Max. Temp** – The cell number with the highest temperature.
- **Min. Volt** – The cell number with the lowest voltage.
- **Max. Volt** – The cell number with the highest voltage.
- **Cycle Count** – Number of times the battery has been fully charged and discharged.

## 2.9 INPUT & OUTPUT POWER

Located further down on the “Monitor” tab, the power curve for Input & Output Power per day can be found. The graph below displays the statistics for Solar PV, Battery, Grid, Consumption, SOC, and AC Coupling. These can also be selected individually to show input & output power.



- A. **Solar PV** – Displayed by a blue line.
- B. **Battery** – Displayed by a green line.
- C. **Grid** – Displayed by a red line.
- D. **Consumption** – Displayed by an orange line.
- E. **SOC** – Displayed by a purple line.
- F. **AC Couple/Generator** – Displayed by a dark blue line.

## 2.10 ENERGY OVERVIEW


At the bottom of the “Monitor” tab is the Energy Overview. This displays the Month, Year, and Total Solar Production, Battery Discharged, Battery Charge, Export to Grid, Import to User, Consumption and AC Couple/Generator.



- A. **Solar Production** – Displayed in light blue.
- B. **Battery Discharged** – Displayed in green.
- C. **Battery Charged** – Displayed in dark blue.
- D. **Export to Grid** – Displayed in red.
- E. **Import to User** – Displayed in brown and shows energy from the grid.
- F. **Consumption** – Displayed in orange and shows how much loads are consuming.
- G. **AC couple/Generator** – Displayed in blue.
- H. **Month** – Select to see energy statistics for each day.
- I. **Year** – Select to see energy statistics for each month.
- J. **Total** – Select to see energy statistics for each year.


### 3. DATA TAB

The “Data” tab displays detailed data, including technical details for PV, battery, grid, and loads, that are helpful for analysis, maintenance, and troubleshooting. The data tab is made up of six pages: Chart, Chart Compare, Energy, Data History, Local Data, and Event History. For more details on each page, see the following tables.




### 3.1 CHART

Displays various parameters in chart format over a 24-hour period. There are separate charts for PV Side, Battery, AC Side, Backup Output, Gen Side, and Internal Sample 1.



### 3.2 CHART COMPARE

Allows comparison of parameters in chart format over a 24-hour period. Separate comparison charts are available for “PV Side”, “Battery”, “AC Side”, “Backup Output”, “Gen Side”, and “Internal Sample”.



The following table gives a brief description of the parameters found in the chart shown on the previous page:

SECTION	NAME	DESCRIPTION
PV Side	Vpv	Voltage of solar input
	Ppv	Power of solar input
Battery	SOC(%)	Battery state of charge
	vBat(V)	Battery voltage
	Charge Power(W)	Total battery charging wattage
	Discharge Power(W)	Total battery discharging wattage
AC Side	Vacr(V)	Voltage of AC output
	Qac(Var)	Reactive power of AC output
	pToGrid(W)	Power being exported to the grid
	pFromGrid(W)	Power being utilized from the grid
	pACoupling(W)	Total power being utilized from AC coupled system
Backup Output	pLoad(W)	Power being utilized for the load
	V Backup Output r(V)	Load rated voltage
	F Backup Output(Hz)	Load frequency
	P Backup Output(W)	Load output power
Gen Side	S Backup Output(VA)	Load apparent power
	GenVolt(V)	Voltage of generator connected to inverter
	GenFreq(Hz)	Frequency of generator connected to inverter
Internal Sample 1	GenPower(W)	Amount of power being utilized from the generator
	vBus2(V)	2 <sup>nd</sup> sample from high voltage BUS
	Vbat_Inv(V)	Voltage sample from batteries after boost
	vBus1(V)	1 <sup>st</sup> sample from high voltage BUS
	vBusP(V)	Total high voltage sample

## 3.3 ENERGY

The “Energy” section displays how key energy parameters have varied over time by Month, Year, and Total.

- Selecting “Month” will show the energy statistics for each day of the month.
- Selecting “Year” will show energy for each month of the year.
- Selecting “Total” will show energy for each year.



NAME	DESCRIPTION
E_pv_all(kWh)	Energy generated by entire PV array
E_pv1(kWh)	Energy generated by PV string 1
E_pv2(kWh)	Energy generated by PV string 2
E_inv(kWh)	Energy output via AC output
E_rec(kWh)	Energy of AC charge
E_charge(kWh)	Energy used for battery charge
E_discharge(kWh)	Energy output by battery discharging
E_backupPower(kWh)	Load energy output
EnergyToGrid(kWh)	Feed-in energy
EnergyFrom Grid(kWh)	Energy import from grid

## 3.4 DATA HISTORY

This page displays the measured technical values of PV, battery, load, and grid for users or their distributor's examination to promptly address any potential issues. Advanced technical knowledge is necessary to properly comprehend this table. End users are advised to concentrate solely on the "Monitor", "Chart", and "Energy" sections as these offer simple to comprehend performance data.



### NOTE:

Data can be exported to an Excel file to be provided to the distributor for technical support. Distributors can then analyze the following factors to perform quick troubleshooting for their end users.

NAME	DESCRIPTION
PtoGrid/PtoUser	Check if CT was connected correctly
Vpv/Ppv	Checks the MPPT
Vo/Po/So	Check the load type and check if there is an overload when in load mode
Vb/SOC	Check the current state of charge and if the battery is overcharged or overly discharged.
Vac/Fac	Evaluate Grid performance and check if working voltage and frequency range is adjusted to comply with grid
E-xxday	Evaluates energy distribution
E-xxall	Checks if the system is working well under off grid mode

## 3.5 LOCAL DATA

The data captured during the offline periods is displayed in the "Local Data" section (loss of internet or Wi-Fi). The only distinction from "Data History" is that it is used for offline data recording. Local data is recorded while the system is offline for more than 20 minutes and is taken every 5 minutes. Data can be stored in the system for a maximum of 90 days.

### 3.6 EVENT HISTORY

The "Event History" page displays a timeline of Notice and Fault events. If there is not a record of a "historical event," the inverter is properly connected and working without any issues.

Station	Serial number	Event Type	Event	Start Time	Time Recovered
1		Notice	W007: LCD communication fault	2025/10/02 08:38:55	
2		Notice	W007: LCD communication fault	2025/10/01 16:28:21	2025/10/02 08:26:51
3		Notice	W000: Communication failure with battery	2025/10/01 16:20:19	2025/10/02 08:26:51
4		Notice	W000: Communication failure with battery	2025/10/01 14:51:47	2025/10/01 14:59:51
5		Notice	W007: LCD communication fault	2025/10/01 14:43:43	2025/10/01 16:16:16
6		Notice	W000: Communication failure with battery	2025/10/01 14:31:37	2025/10/01 14:35:39
7		Notice	W000: Communication failure with battery	2025/10/01 14:03:24	2025/10/01 14:25:33
8		Notice	W027: Battery open	2025/10/01 13:59:22	2025/10/02 08:38:55



#### NOTE:

Certain features shown in this guide are only available on select EG4® inverter models and certain tiers of customer account access.

### 4. CONFIGURATION TAB

The "Configuration" tab is designated for users to manage their Stations, Dongles, Devices, and User information.

Station name	EndUser	Country	Timezone	Daylight saving time	Create date	Action
1		United States of America	GMT -6	Yes	2025-07-30	Station Management
2		United States of America	GMT -6	Yes	2025-06-23	Station Management
3		United States of America	GMT -6	Yes	2024-09-11	Station Management
4		United States of America	GMT -6	Yes	2024-08-28	Station Management
5		United States of America	GMT 0	Yes	2024-07-29	Station Management
6		United States of America	GMT -5	Yes	2024-05-31	Station Management

#### 4.1 STATIONS

The "Stations" page will show all stations linked to the account. Selecting a station name will display all inverters under that station or location.

Selecting the "Add Station" button creates another site if there is more than one station under the same account. This is useful for distributors who have multiple customers who would like assistance with monitoring/troubleshooting their inverters.

Station name	EndUser	Country	Timezone	Daylight saving time	Create date	Action
1		United States of America	GMT -6	Yes	2025-07-30	Station Management
2		United States of America	GMT -6	Yes	2025-06-23	Station Management
3		United States of America	GMT -6	Yes	2024-09-11	Station Management
4		United States of America	GMT -6	Yes	2024-08-28	Station Management
5		United States of America	GMT 0	Yes	2024-07-29	Station Management
6		United States of America	GMT -5	Yes	2024-05-31	Station Management

## 4.2 DONGLES

Users can add a dongle Serial Number (SN) to the station if they have more than one inverter in the station. The inverter will be shown on the system once the dongle has been properly configured to communicate with the server and the inverter has been powered on.



### IMPORTANT:

Before configuring the password for the Wi-Fi dongle, add the dongle to the monitor center.

Serial number	Dongle type	Station name	EndUser	Firmware	Create date	Connect Status	Last Update Time	Action
1	WIFI				2025-10-06	Lost	2025-10-06 15:46:32	Management
2	Wi-Fi				2025-09-02	Lost	2025-10-03 09:05:00	Management
3	Wi-Fi				2024-08-20	Lost	2025-10-02 11:03:30	Management
4	Wi-Fi				2024-10-15		2024-09-04 12:58:33	Management
5	Wi-Fi				2024-11-08	Connected	2025-10-07 12:31:06	Management
6	Wi-Fi				2024-08-05	Lost	2024-08-24 18:30:04	Management

## 4.3 DEVICES

The “Devices” page displays any inverter tied to the user’s account, listed by serial number. Data can be exported to an Excel file for record keeping or to view specific inverter stats.

Serial number	Dongle	Station name	EndUser	Device type	Battery type	Power Rating	Firmware	Status	Connect Status	Last Update Time	BattParallelN	BattCapacity	Export	Action
1				18KPV	Lead-acid ba	12kW	FAAB-0E0E	Standby	Lost	2024-04-02 23:20:3 0	600	false	Management	
2				18KPV	Lithium batt	12kW	FAAB-E7E7	Fault	Lost	2024-07-24 08:34:0 0	0	false	Management	
3				18KPV	Lithium batt	12kW	FAAB-2122	Battery Grid on	Lost	2025-07-17 16:01:0 3	840	true	Management	
4				18KPV	Lithium batt	12kW	FAAB-2522	Standby	Connected	2025-10-07 13:58:5 1	280	true	Management	
5				18KPV	Lithium batt	12kW	FAAB-2021	Battery Grid on	Connected	2025-10-07 13:58:2 1	280	true	Management	
6				12KPV	Lithium batt	8kW	EAA8-1515	Fault	Lost	2024-07-23 16:28:1 0	0	true	Management	


## 4.4 USERS

The “Users” page shows a full list of users, distributors and any other roles linked to the account. End users can modify passwords and edit personal information in the user page under the “User Management” drop down box. Distributors can add installer or end user accounts on this page.

Username	Nickname	Role	E-mail	Country	Timezone	Tel number	Address	Create date	User Permis	Installer Code	Tech support typ	Tech suppor	Cluster	Action
1				United Sta	GMT -6			2025-09-18	Normal				North	User Management
2				United Sta	GMT -6								North	User Management


## 4.5 USER MIGRATION RECORD

The “User Migration Record” page tracks changes made to user accounts, including the transfer of end users and dongles. This feature enables installers to manage and monitor user accounts effectively, ensuring that all modifications are recorded for transparency and accountability.




## 5. OVERVIEW TAB

The “Overview” tab allows EG4® or its distributors to quickly monitor system-wide data for their end users, such as solar yields, battery discharging, and other factors.




### 5.1 STATION OVERVIEW

All the stations linked to the account can be found here. Selecting a station name will switch the main page to show the real time data.



### 5.2 DEVICE OVERVIEW

All the inverters linked to the account can be found here. Selecting a serial number will switch the main page to show the real time data for that inverter.






## NOTE:

Certain features shown in this guide are only available on select EG4® inverter models and certain tiers of customer account access.


## 6. MAINTENANCE TAB

The “Maintenance” tab is used to remotely change settings on the inverter by selecting a station and then an inverter serial number. The Maintenance tab includes Remote Set, Weather Optimize, and Remote Update.



### 6.1 REMOTE SET

The “Remote Set” page is used to configure inverter settings. Select the station to begin configuring settings. Each sub-section is explained below.



## Common Settings

▼
Common Setting

**Time (?)**

**PV Input Mode (?)**

**Start PV Volt(V)**

**Neutral Detect Enable (?)**

**Model**

**Measurement (?)**

**Battery Type (?)**

**Lithium Brand (?)**

**Firmware version**

**LCD Version**

**LCD Password (?)**

- **Time:** Set the time/date of the inverter. The input format is 2019-02-14 14:44:00 (YYYY-MM-DD HH:MM:SS)
- **PV Input Mode:** The connection type of solar modules.
- **Neutral Detect Enable:** Auto detects connection of the grid neutral and PE line. When enabled, will show fault if no neutral or PE line is detected.
- **Start PV Volt (V):** Voltage at which the MPPT utilizes solar for loads/charging.
- **Measurement:** Choose the correct “Measurement” according to Meter Type or CT Sample Ratio according to the external measuring device that is installed. The default measurement is 1000/1. The measurement can be adjusted if there is a meter connected to the inverter.
- **Battery Type:** Choose the “Battery Type” and then select Lithium Brand (for closed-loop communications), or battery capacity for lead-acid/lithium batteries with no communications.  
*Note: after setting the battery type, all other settings will reset to default.*
- **Lithium Brand:** Choose the brand of lithium battery being used.
- **Firmware version:** Shows the current firmware version being used.
- **LCD Version:** Shows the current LCD version being used.
- **LCD Password:** Distributor or installer can only set/change the password.



### NOTE:

When the “Model” settings need to be changed, users need to set inverter to “Standby” in the Application Settings menu first, then select “Set Model” to change the model.

## Application Settings

▼ Application Setting

<p>EPS Voltage Set(V) (?) <input type="text" value="&lt;Empty&gt;"/> <input type="button" value="Set"/></p> <p>Power Backup (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p>Grid Sell Back (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p>Fast Zero Export (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p>PV Arc (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p>Grid Loss Warning Clear (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p>Normal / Standby (?) <input type="button" value="Normal"/> <input type="button" value="Standby"/></p> <p>Micro-Grid (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p>System Charge SOC Limit(%) <input type="text" value="[10, 101]"/> <input type="button" value="Set"/></p>	<p>No Batteries (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p>Seamless EPS switching (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p>Grid Sell Back Power(kW) (?) <input type="text" value="[0, 25.5]"/> <input type="button" value="Set"/></p> <p>Off-Grid Mode (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p>PV Arc Fault Clear (?) <input type="button" value="Clear"/></p> <p>RSD (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p>Restart Inverter (?) <input type="button" value="Restart"/></p> <p>Max. AC Input Power(kW) (?) <input type="text" value="[0, 6553.5]"/> <input type="button" value="Set"/></p> <p>System Charge Volt Limit(V) <input type="text" value="[40, 59.5]"/> <input type="button" value="Set"/></p>
<div style="border: 1px solid #ccc; padding: 5px; margin-top: 10px;"> <p><b>Parallel System</b></p> <p>Set System Type (?) <input type="text" value="&lt;Empty&gt;"/> <input type="button" value="Set"/></p> <p>Share Battery (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p>Set Composed Phase (?) <input type="text" value="&lt;Empty&gt;"/> <input type="text" value="&lt;Empty&gt;"/> <input type="button" value="Set"/></p> <p>Parallel Setting Data Sync (?) <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> </div>	

- **EPS Voltage Set(V):** Sets the voltage to accommodate the rated grid voltage.
- **No Batteries:** Allows access to off-grid mode when only solar input is available without battery storage.
- **Power Backup:** If “Power Backup” function is Enabled, the LOAD terminal will maintain output when AC is interrupted. “Power Backup” can be set via the web or “Off-Grid Output” by LCD. (When enabling this mode, the inverter’s output will be uninterrupted.)
- **Seamless EPS Switching:** When power is interrupted, the inverter will seamlessly switch to EPS mode unless there is a grid voltage fluctuation issue; in which case, we suggest setting to “Disable” to avoid misjudgment.
- **Grid Sell Back:** In some cases, the customer cannot feed energy into grid. If the customer does not want to feed energy to the grid, the “Grid Sell Back” function can be disabled.
- **Grid Sell Back Power(kW):** If “Grid Sell Back” function is enabled, the power limitation feed can be adjusted.
- **Fast Zero Export:** Normally, the inverter will adjust output power every 5 seconds to avoid export. If “Fast Zero Export” is enabled, the inverter will adjust output power accordingly.
- **Off-Grid Mode:** Enable for nominal Off-Grid operations while utilizing AC input as a backup power source, allowing for absolute zero export.
- **PV Arc:** The inverter will detect when there is an arc fault on the PV inputs in order to protect itself from potential damage.
- **PV Arc Fault Clear:** Clear the records of PV arc fault.
- **Grid Loss Warning Clear:** Enable for an absolute Off-Grid system. The “No AC Connection” and “AC V /F out of range” warning will not occur when enabled.
- **RSD:** The rapid shut-down detection of the PV inputs.
- **Normal/Standby:** “Standby” is used to set the system into standby mode, stopping feed in, charge and discharge. “Normal” is used to set the whole system to auto run status.
- **Restart Inverter:** Restarts the inverter.

- **Micro-Grid:** Should be set only when the generator is connected to the Inverter’s Grid terminal. With this option enabled, the inverter will use AC power to charge the battery and will not export any power through the Grid terminal if AC power is present at the inverter’s Grid terminal.
- **Max. AC Input Power(kW):** The inverter can adjust the charge power based on the detected inverter’s load consumption and “Max. AC Input Power(kW)” limitation.
- **System Charge SOC Limit(%):** The limit to which the battery can be charged measured by SOC%. Once set, the battery SOC will not exceed the set value.
- **System Charge Volt Limit(V):** The limit to which the battery can be charged measured by voltage. Once set, the battery voltage will not exceed the set value.

Parallel System

Set System Type (?)	<input type="text" value="&lt;Empty&gt;"/>	<input type="button" value="Set"/>	Share Battery (?)	<input type="button" value="Enable"/>	<input type="button" value="Disable"/>
Set Composed Phase (?)	<input type="text" value="&lt;Empty&gt;"/>	<input type="text" value="&lt;Empty&gt;"/>	Parallel Setting Data Sync (?)	<input type="button" value="Enable"/>	<input type="button" value="Disable"/>

- **Set System Type:** EG4® inverters support paralleling of multiple inverters. In this scenario, one of the inverters must be set to Master and the others set to Slave. If all inverters are installed as single-phase, be sure to set one of the inverters to “1 Phase Master.” If a three-phase system is needed, set one of the inverters to “3 Phase Master.” All inverters are set to Slaves by default. Upon purchase/receipt of the inverters, one will need to be set to Master before paralleling multiple inverters.
- **Share Battery:** For paralleled systems: if all inverters connect to same battery bank, “Share Battery” must be enabled. The Master inverter will broadcast the battery information to all other inverters.
- **Set Composed Phase:** When using  $\geq 3$  inverters to compose a three-phase system, the AC terminals of the inverter must be connected to a three-phase grid. If the system is connected to the grid, the inverter will detect the phase it connects to automatically, record it and output the phase as it detected. If the user setting is different from the phase the inverter detected, it will output the phase detected. The output phase record will be cleared if the customer clears it. If the system is not connected to the grid, the inverter will use the user output phase setting to compose the three-phase output. If the customer sets the wrong phase (i.e., 2 U phase and no W phase) the system will report error.
- **Parallel Setting Data Sync:** Syncs master inverter settings to those of the slave inverter(s).

## System Grid Connect Settings

System Grid Connect Setting

Grid Regulation (?) <Empty> Set

Grid Frequency(Hz) (?) <Empty> Set      Grid Type (?) <Empty> Set

**Connection**

Connect Time(s) (?) [0, 600] Set      Reconnect Time(s) (?) [0, 3600] Set

Grid Volt Connect Low(V) (?) Set      Grid Volt Connect High(V) (?) Set

Grid Freq Connect Low(Hz) (?) Set      Grid Freq Connect High(Hz) (?) Set

**Power Command**

Active Power Percent(%) (?) [0, 100] Set

**Grid Protection**

- **Grid Regulation:** Select the correct grid safety regulation.
- **Grid Frequency(Hz):** If the “Grid Frequency” is nominal at 50Hz, then the inverter’s frequency will be adjusted to 50Hz automatically. If there is no grid power and it is read as 50Hz, but the devices are 60Hz, then it can be set to 60Hz manually. This is based on the rated frequency of the local grid regulation and devices.
- **Grid Type:** Select the correct “Grid type” to function, such as split phase: 240/120 or 208/120V.
- **Connect Time(s):** The wait time to connect to the grid if the solar input is ready and the grid power is in range of the voltage and frequency settings below.
- **Reconnect Time(s):** The inverter will attempt to reconnect to the grid after abnormal situations (i.e. voltage/frequency fluctuations) once this amount of time has elapsed.
- **Grid Volt Connect Low(V):** Voltage range of grid connect.
- **Grid Volt Connect High(V):** Voltage range of grid connect.
- **Grid Freq Connect Low(Hz):** Frequency range of grid connect.
- **Grid Freq Connect High(Hz):** Frequency range of grid connect.
- **Active Power Percent(%):** Max AC Output power percent of the inverter.



### WARNING:

Settings should be adjusted while the device is on Standby. Ensure this setting is correctly configured before powering on the system. Using the wrong power frequency can lead to home appliance damage.

## Charge Settings

Charge Setting

Batt Charge Control (?)  Volt  SOC Charge Current Limit(Adc) (?) [0, 250] Set

Charge Last (?)  Enable  Disable

Battery Backup Mode  Enable  Disable

---

AC Charge

AC Charge Enable (?)  Enable  Disable AC Charge Based On (?) <Empty> Set AC Charge Power(kW) (?) [0, 25.5] Set

Start AC Charge SOC(%) [0, 90] Set Start AC Charge Volt(V) [40, 57] Set

Stop AC Charge SOC(%) [0, 100] Set Stop AC Charge Volt(V) [42, 59] Set

AC Charge Start Time 1 [0, 23] : [0, 59] Set AC Charge Start Time 2 [0, 23] : [0, 59] Set AC Charge Start Time 3 [0, 23] : [0, 59] Set

AC Charge End Time 1 [0, 23] : [0, 59] Set AC Charge End Time 2 [0, 23] : [0, 59] Set AC Charge End Time 3 [0, 23] : [0, 59] Set

---

Battery Backup Mode

PV Charge Priority (?)  Enable  Disable PV Charge Power(kW) [0, 25.5] Set

PV Charge Priority Stop SOC(%) (?) [0, 100] Set PV Charge Priority Stop Volt(V) [48, 59] Set

Battery Priority Start Time 1 [0, 23] : [0, 59] Set Battery Priority Start Time 2 [0, 23] : [0, 59] Set Battery Priority Start Time 3 [0, 23] : [0, 59] Set

Battery Priority End Time 1 [0, 23] : [0, 59] Set Battery Priority End Time 2 [0, 23] : [0, 59] Set Battery Priority End Time 3 [0, 23] : [0, 59] Set

- **Battery Charge Control:** If the inverter communicates with the lithium battery and is capable of closed-loop communication, then select “Batt. Charge Control” according to “SOC.” If communication is not available, users can select “Batt. Charge Control” according to “VOLT.”
- **Charge Current Limit (Adc):** The maximum charge current limitation of the entire system.
- **Charge Last:** Charges battery last.
- **AC Charge Enable:** If using AC (i.e., the Grid) to charge the battery, the customer must (1) “Enable” AC Charge Enable, (2) set the max power to charge the battery from AC; “AC Charge Power (kW)”, (3) set the SOC and Voltage Limits; “Start AC Charge SOC(%) / Volt(V)” and “Stop AC Charge SOC (%) / Volt(V)” and (4) set the time period to use the AC to charge the battery. There are 3 time periods that can be set. If the battery SOC and Voltage is within the limits, the system will use AC from the Grid to charge the battery during the time that is set.
- **AC Charge Based On:** According to time: Set a preferred time period to charge the battery range: 00:00 – 23:59. According to voltage: Set AC to charge the battery when it drops to a pre-set voltage. Range: 50-59V.
- **AC Charge Power (kW):** The max charging power from grid.
- **AC Charge:** Set AC charging according to Time or Volt(V)/SOC (%).
- **Start AC Charge SOC(%) / Volt(V):** Limit of SOC and Voltage at which system will start charging batteries from AC.
- **Stop AC Charge SOC(%) / Volt(V):** Limit of SOC and Voltage at which system will stop charging batteries from Grid.
- **AC Charge Start Time 1-3:** Start AC Charging according to these time settings.
- **AC Charge End Time 1-3:** Stop AC Charging according to these time settings.
- **PV Charge Priority:** In this mode, solar will charge battery first. After charging batteries, solar will supply any loads. Lastly, it will feed into the grid if surplus power is generated.
- **PV Charge Power(kW):** The max charging power from solar.
- **PV Charge Priority Stop SOC (%):** When SOC reaches this limit, charge first mode will end.
- **PV Charge Priority Stop Volt (V):** When voltage reaches this limit, charge first mode will end.
- **Battery Priority Start Time 1-3:** Start time for charge first setting.
- **Battery Priority End Time 1-3:** End time for charge first setting.

## Generator Charge Settings

Generator Charge

---

**Generator**

<p><b>Generator Boost</b> <input type="button" value="Enable"/> <input type="button" value="Disable"/></p> <p><b>Batt Charge Current Limit(Adc) (?)</b> <input type="text" value="[0, 4000]"/> <input type="button" value="Set"/></p> <p><b>Charge Start Volt(V) (?)</b> <input type="text" value="[40, 57]"/> <input type="button" value="Set"/></p> <p><b>Charge End Volt(V)</b> <input type="text" value="[42, 59]"/> <input type="button" value="Set"/></p>	<p><b>Generator Cool-Down Time(Min)</b> <input type="text" value="[0.1, 25.5]"/> <input type="button" value="Set"/></p> <p><b>Gen Rated Power(kW) (?)</b> <input type="text" value="[0, 25.5]"/> <input type="button" value="Set"/></p> <p><b>Charge Start SOC(%)</b> <input type="text" value="[0, 100]"/> <input type="button" value="Set"/></p> <p><b>Charge End SOC(%)</b> <input type="text" value="[0, 100]"/> <input type="button" value="Set"/></p>
---	---

- **Generator Boost Enable/Disable:** Enable or disable the generator boost feature. Enable to allow the inverter to pull supplemental power from both PV and battery whenever the generator power is not sufficient to handle all loads.
- **Generator Cool-Down Time(Min):** Set the cool-down time period for the generator before re-engaging the generator's output to the inverter.
- **Batt Charge Current Limitation(Adc):** Battery charge current limitation from Generator.
- **Gen Rated Power(kW):** The battery charge power can be limited based on the detected inverter's load consumption and Generator input power limitations.
- **Charge Starts Volt(V)/SOC(%):** While using auto-start function of the generator, the "Charge Start Voltage / SOC (%)" can be limited to start up the generator automatically.
- **Charge End Volt(V)/SOC(%):** While using auto-start function of the generator, the "Charge End Voltage / SOC (%)" can be limited to turn off the generator automatically.

## Discharge Settings

- **Batt Discharge Control:** If the inverter communicates with the lithium battery and is capable of closed-loop communication, users should select “Batt. Discharge Control” according to “SOC.” When using lead-acid batteries or lithium batteries without communication, users should select discharge control according to “VOLT.”
- **Discharge Current Limit (Adc):** The Max. discharge current limit when grid power is on.
- **Start Discharge P\_Import(W):** Default value is 100 which means the battery will begin to discharge power to take the load when the import power from grid is higher than 100W. (Adjust range [50-100]).
- **On-Grid Cut-Off SOC(%)/Volt(V):** When the inverter connects to the grid and if the battery is discharging to take the load, it will stop discharge when the SOC/Voltage is lower than this limit.
- **Off-Grid Cut-Off SOC(%)/Volt(V):** When the inverter is not connected to the grid and the battery is discharging to take the load, the battery will stop discharging when the SOC/Voltage is lower than this limit.
- **Forced Discharge Enable/Disable:** If the customer wants to simply discharge the battery, they can enable forced discharge function and set both the discharge power and time period.
- **Forced Discharge Power(kW):** Forced discharge power limit.
- **Stop Discharge SOC(%)/Volt(V):** If Battery SOC is lower than this limit, the inverter will stop forced discharging function.
- **PV Sell To Grid (Comp. w/ NEM3.0):** Enable or disable PV sell back to grid feature.
- **Forced Discharge Start Time 1-3:** Start time for Forced Discharge.
- **Forced Discharge End Time 1-3:** End time for Forced Discharge.
- **Grid Peak-Shaving:** Peak-Shaving is used to avoid peak demand charges from the grid. Peak shaving can be accomplished by halting Grid Charging at specific times. For example, during periods of peak demand (i.e., high grid rates), or when the batteries are near fully charged based on SOC and Voltage.
- **Grid Peak-Shaving Power 1-2(kW):** Used to set the maximum power that the inverter can draw from the grid.
- **Start Peak-Shaving Volt(V)/SOC(%) 1-2:** The point at which Peak-Shaving starts.

- **Peak-Shaving Start Time 1-2:** The time of day at which charging by the grid will be halted.
- **Peak-Shaving End Time 1-2:** The time of day at which charging by the grid will resume.
- **AC Couple Enable/Disable:** When connecting an existing on-grid system to the GEN terminal, AC Couple must be set to enable.
- **AC Couple Start Volt(V)/SOC (%):** AC Coupling will start at this set Voltage/SOC.
- **AC Couple Stop Volt(V)/SOC (%):** AC Coupling will stop at this set Voltage/SOC.
- **Smart Load Enable/Disable:** When Smart load function is enabled, the GEN terminal will be reused to Smart Load, and the inverter will offer power to this load based on the setup values.
- **Start PV Power (kW):** This is the minimum PV power limit to function with smart load output.
- **On Grid Always On:** Once this function is enabled, smart load will always function when grid power is on.
- **Smart Load Start SOC (%) / Volt (V):** The high limit for battery to turn on smart load.
- **Smart Load Stop SOC (%) / Volt (V):** The low limit for battery to turn off smart load.

## Battery

∨ Battery
Read

Restart Battery Module 0

Restart Battery Module

- **Restart battery module:** Restarts the battery.

## Reset

∨ Reset


All to Default Reset
Clear Function Set

- **Reset:** Reset all settings to default.

## 6.2 WORKING MODE SETTINGS PAGE

The Working Mode settings page has several options and settings to allow different preset working modes that allow the user to further customize and configure the system to meet their needs. Working modes include Backup Mode, Peak Shaving, AC Charge Mode, PV Charge Priority, Forced Discharge/Export PV Only, and Self Consumption.


To switch to the Working Mode settings page, select the “Working Mode” button in the top right corner of the monitor center.



### NOTE:

Certain features shown in this guide are only available on select EG4® inverter models and certain tiers of account access.


## Device Information



The Device Information tab displays the current time, firmware version, and LCD version at a glance. The user is also able to change their LCD display's password.

## APPLICATION SETTING TAB

### Basic settings:



### General

- **Normal/Standby:** “Standby” is used to set the system into standby mode, stopping feed in, charge and discharge. “Normal” is used to set the whole system to auto run status.
- **Restart Inverter:** Restarts the inverter.
- **Off-Grid Mode:** Enable for nominal Off-Grid operations while utilizing AC input as a backup power source, allowing for absolute zero export.
- **Grid Loss Warning Clear:** Enable for an absolute Off-Grid system. The “No AC Connection” and “AC V /F out of range” warning will not occur when enabled.
- **Max. AC Input Power(kW):** The inverter can adjust the charge power based on the detected inverter’s load consumption and “Max. AC Input Power(kW)” limitation.
- **Dry Contact Reuse:** This function can be configured with Dry Contact #2 for use with Null, RSD, Dark Start, Smart Load, and Non-Critical Loads to work with additional relay or contactor.

### EPS Output

- **Power Backup:** If “Power Backup” function is Enabled, the LOAD terminal will maintain output when AC is interrupted. “Power Backup” can be set via the web or “Off-Grid Output” by LCD. (When enabling this mode, the inverter’s output will be uninterrupted.)
- **Seamless EPS Switching:** When power is interrupted, the inverter will seamlessly switch to EPS mode unless there is a grid voltage fluctuation issue; in which case, we suggest setting to “Disable” to avoid misjudgment.
- **No Batteries:** Allows access to off-grid mode when only solar input is available without battery storage.
- **EPS Voltage Set(V):** Set the voltage to accommodate the grid voltage. Options: 202, 208, 220, 230, 240.


## Protection Setting

- **RSD:** The rapid shut-down detection of the PV inputs.
- **PV Arc:** The inverter will detect when there is an arc fault on the PV inputs in order to protect itself from potential damage.
- **PV Arc Fault Clear:** Clear the records of PV arc fault.

## Grid Sell

- **Grid Sell Back:** In some cases, the customer cannot feed energy into grid. If the customer does not want to feed energy to the grid, the “Grid Sell Back” function can be disabled.
- **Grid Sell Back Power(kW):** If “Grid Sell Back” function is enabled, the power limitation feed can be adjusted.
- **Fast Zero Export:** Normally, the inverter will adjust output power every 5 seconds to avoid export. If “Fast Zero Export” is enabled, the inverter will adjust output power accordingly.

## Advanced settings:



## Parallel Setting

- **Grid Boss Enable:** Set to enable if the system is utilizing a GridBOSS.
- **Set System Type:** EG4® inverters support paralleling of multiple inverters. In this scenario, one of the inverters must be set to Master and the others set to Slave. If all inverters are installed as single-phase, be sure to set one of the inverters to “1 Phase Master.” If a three-phase system is needed, set one of the inverters to “3 Phase Master.” All inverters are set to Slaves by default. Upon purchase/receipt of the inverters, one will need to be set to Master before paralleling multiple inverters.
- **Parallel Setting Data Sync:** Syncs master inverter settings to those of the slave inverter(s).
- **Detected Grid Phases:** Used to remove the detected phase to clear the warning code of phases inconsistency.
- **Set Composed Phase:** When using  $\geq 3$  inverters to compose a three-phase system, the AC terminals of the inverter must be connected to a three-phase grid. If the system is connected to the grid, the inverter will detect the phase it connects to automatically, record it and output the phase as it detected. If the user setting is different from the phase the inverter detected, it will output the phase detected. The output phase record will be cleared if the customer clears it. If the system is not connected to the grid, the inverter will use the user output phase setting to compose the three-phase output. If the customer sets the wrong phase (i.e., 2 U phase and no W phase) the system will report error.

## Protection Setting

- **Neutral Detect Enable:** Automatically detects connection of the grid’s neutral and ground line. When enabled, will show fault if no neutral or ground line is detected.

## CT/Meter Setting

- **Measurement:** Choose the correct “Measurement” according to Meter Type or CT Sample Ratio according to the external measuring device that is installed. The default measurement is 1000/1. The measurement can be adjusted if there is a meter connected to the inverter.
- **Busbar PCS Rating(A):** Enter the panel’s current rating or service rating. The system will automatically begin to limit output current once it reaches 80% of the entered busbar rating. This behavior aligns with NEC requirements for continuous current ratings, which commonly apply the 80% rule for long-term loading.

## PV Setting

- **PV Input Mode:** The connection type of solar modules.
- **Start PV Volt (V):** Voltage at which the MPPT utilizes solar for loads/charging.

## Working Mode Setting Tab


The steps to access the specific working modes and a brief description of the modes are outlined below.



### NOTE:

Certain features shown in this guide are only available on select EG4® inverter models and certain tiers of account access.

1. In the “Maintenance” tab on the Remote Set page, ensure that the correct station is selected. Select “Read” (*shown below*) for the Monitor Center to fetch the default or pre-configured settings for the station. Located to the top right of the page, select “Working Mode”.



2. After “Working Mode” is selected, navigate below Application Settings for the “Working Mode Setting” section (*shown below*). This section gives users access to configure the system to their own needs by utilizing both settings and time of use periods.



## Backup Mode

Working Mode Setting

- Active Mode
- Backup Mode**
- Peak Shaving Mode
- AC Charge Mode
- PV Charge Priority Mode
- Forced Discharge Mode/Export PV Only Mode
- Self Consumption Mode

01:00 03:00 05:00 07:00 09:00 11:00 13:00 15:00 17:00 19:00 21:00 23:00

**Battery Backup Mode**  Enable  Disable

AC Charge Power(kW) (?)  0kW

Backup SOC(%) (?)

Backup Volt(V) (?)

**Start**     **End**

**Battery Backup Mode:** The system prioritizes battery backup/storage by ensuring the battery is only utilized as a last resort when PV and Grid power is not sufficient for powering loads.

- **AC Charge Power (kW):** The maximum charging power from grid.
- **Backup SOC(%):** Set the maximum SOC for backup. This parameter is the same as Stop AC Charge SOC.
- **Backup Volt(V):** Set the maximum Voltage for backup. This parameter is the same as Stop AC Charge Volt.
- **Start/End Times:** Set times to begin and end Backup Mode.

## Peak Shaving

Working Mode Setting

- Active Mode
- Backup Mode
- Peak Shaving Mode**
- AC Charge Mode
- PV Charge Priority Mode
- Forced Discharge Mode/Export PV Only Mode
- Self Consumption Mode

01:00 03:00 05:00 07:00 09:00 11:00 13:00 15:00 17:00 19:00 21:00 23:00

**Grid Peak-Shaving 1** [Enable] [Disable]

Grid Peak-Shaving Power(kW) [0, 25.5] Set

Start Peak-Shaving Volt 1(V) [40, 59] Set

Start Peak-Shaving SOC 1(%) [0, 100] Set

Start: [T1] [0, 23] : [0, 59] Set

End: [0, 23] : [0, 59] Set

**Grid Peak-Shaving 2**

Grid Peak-Shaving Power2(kW) [0, 25.5] Set

Start Peak-Shaving Volt 2(V) [40, 59] Set

Start Peak-Shaving SOC 2(%) [0, 100] Set

Start: [T2] [0, 23] : [0, 59] Set

End: [0, 23] : [0, 59] Set

**Grid Peak Shaving:** The user can define a time-frame of when the system will compensate the power pulled from the grid for loads during peak demand times to avoid higher electricity rates.

- **Grid Peak-Shaving Power(kW)/Grid Peak-Shaving Power2(kW):** Set the maximum amount of power that will be drawn from the grid.
- **Start Peak-Shaving Volt 1(V)/Start Peak-Shaving Volt 2(V):** Set the starting point of peak-shaving when using voltage setpoints for batteries.
- **Start Peak-Shaving SOC 1(%) / Start Peak-Shaving SOC 2(%):** Set the starting point of peak-shaving when using SOC setpoints for batteries.
- **T1/T2 Start/End:** Set the start/end time of peak-shaving depending on SOC/voltage as configured above.

## AC Charge Mode

The screenshot shows the 'Working Mode Setting' interface. On the left, there is a vertical list of mode buttons: Active Mode, Backup Mode, Peak Shaving Mode, **AC Charge Mode** (highlighted in yellow), PV Charge Priority Mode, Forced Discharge Mode/Export PV Only Mode, and Self Consumption Mode. To the right of these buttons is a large empty grid area with a time axis from 01:00 to 23:00. Below the grid, there are two main configuration panels. The left panel, titled 'AC Charge Enable', has an 'Enable' button and a 'Disable' button. It contains several settings: 'AC Charge Power(kW)' with a slider and a 'Set' button; 'AC Charge Based On' with a dropdown menu and a 'Set' button; 'Start AC Charge SOC(%)' with a text input and a 'Set' button; 'Stop AC Charge SOC(%)' with a text input and a 'Set' button; 'Start AC Charge Volt(V)' with a text input and a 'Set' button; and 'Stop AC Charge Volt(V)' with a text input and a 'Set' button. The right panel, titled 'Sporadic Charge', has an 'Enable' button and a 'Disable' button. It contains three rows of time settings labeled T1, T2, and T3. Each row has a 'Start' and 'End' time range with 'Set' buttons.

**AC Charge Enable:** Allows the grid to both charge batteries and power loads.

**Sporadic Charge:** When enabled alongside AC Charge Mode, the AC charging power will be sporadic between the set AC charge power and 2% of the rated charge power.

- **AC Charge Power(kW):** Set the maximum power drawn from the grid to charge batteries.
- **AC Charge Based On (SOC/Volt/Time):** Configure how the system will charge batteries from the grid by setting custom voltage points, SOC of batteries, or by time.
- **Start/Stop AC Charge SOC(%):** Set the starting point of AC Charging when using SOC setpoints for batteries.
- **Start/Stop AC Charge Volt(V):** Set the starting point of AC Charging when using voltage setpoints for batteries.
- **T1/T2/T3 Start/End:** Set the start/end time of AC Charge mode depending on SOC/voltage as configured above.

## PV Charge Priority

Working Mode Setting

Active Mode

Backup Mode

Peak Shaving Mode

AC Charge Mode

**PV Charge Priority Mode**

Forced Discharge Mode/  
Export PV Only Mode

Self Consumption Mode

01:00 03:00 05:00 07:00 09:00 11:00 13:00 15:00 17:00 19:00 21:00 23:00

PV Charge Priority (?) Enable Disable

PV Charge Power(kW) (?) 0kW [0, 25.5] Set

PV Charge Priority Stop SOC(%) (?) [0, 100] Set

PV Charge Priority Stop Volt(V) (?) [48, 59] Set

	Start	End
T1	[0, 23] : [0, 59] Set	[0, 23] : [0, 59] Set
T2	[0, 23] : [0, 59] Set	[0, 23] : [0, 59] Set
T3	[0, 23] : [0, 59] Set	[0, 23] : [0, 59] Set

**PV Charge Priority:** Prioritizes PV power to charge batteries first. The order of priority for solar power usage will be Battery >Load >Grid. During the “PV Charge Priority” period, loads are first supplied power from the grid. If there is excess solar power after charging batteries, the excess solar will power the loads along with grid power.

- **PV Charge Power(kW):** Set the maximum amount of power to charge the batteries from solar.
- **PV Charge Priority Stop SOC(%)/Volt:** Set the stop point for PV Charge Priority according to SOC or Voltage.
- **T1/T2/T3 Start/End:** Set up to three different start and stop times for the PV Charge Priority working mode.

## Forced Discharge Mode/Export PV Only Mode

Working Mode Setting

Active Mode

Backup Mode

Peak Shaving Mode

AC Charge Mode

PV Charge Priority Mode

Forced Discharge Mode/Export PV Only Mode

Self Consumption Mode

01:00 03:00 05:00 07:00 09:00 11:00 13:00 15:00 17:00 19:00 21:00 23:00

Forced Discharge Enable (?) Enable Disable

Export PV Only (?) Enable Disable

Forced Discharge Power(kW) (?) [0, 25.5] Set

Stop Discharge SOC(%) (?) [0, 100] Set


Stop Discharge Volt(V) [40, 56] Set

	Start	End
T1	[0, 23] : [0, 59] Set	[0, 23] : [0, 59] Set
T2	[0, 23] : [0, 59] Set	[0, 23] : [0, 59] Set
T3	[0, 23] : [0, 59] Set	[0, 23] : [0, 59] Set

**Forced Discharge/Export PV Only:** Forced discharge prioritizes battery power for powering loads and grid sell back. Export PV Only prioritizes PV power to export to the power grid.

- **Export PV Only:** Enable this setting to sell back generated PV power to the grid.
- **Forced Discharge Power(kW):** Set the maximum power limit of battery discharge.
- **Stop Discharge SOC(%) / Volt:** Stop the forced discharge upon reaching the set SOC/ voltage point.
- **T1/T2/T3 Start/End:** Set up to three different start and stop times for the Force Discharge/Export PV Only working mode.

## Self Consumption




**Self Consumption:** Prioritizes the energy stored/generated from the system to power loads. The system will default to Self-Consumption mode. The order of priority for powering loads is Solar > Battery > Grid. The order priority for solar power is Load > Battery > Grid which creates an ideal scenario when needing to prioritize solar power generation over other types of power. Self-Consumption mode will increase the self-consumption rate of solar power and reduce energy bills significantly. Effective when Charge Priority, AC Charge, and Forced Discharge are disabled.

Upon selecting a “Working Mode”, the system must be configured using specific settings for each mode.

## Export PDF

The “Export PDF” feature creates a PDF document with the system’s selected settings and values for ease of troubleshooting. To use the Export PDF function, ensure the correct station is selected. Select “Read” for the Monitor Center to fetch the default or pre-configured settings for the station. If “Read” is not selected before trying to Export PDF, the PDF will be missing the specified settings and values. Next, select “Export PDF” (*shown below*) to create a document showing the system settings.



## BATTERY SETTING

- **Battery Type:** Choose the “Battery Type” and then select Lithium Brand (for closed-loop communications), or battery capacity for lead-acid/lithium batteries with no communications. *Note: after setting the battery type, all other settings will reset to default.*
- **Lithium Brand / No comms:** Choose the brand of lithium battery being used.

### Charging

- **Batt Charge Control:** When communicating in closed-loop, select charge control according to ‘SOC’. When not communicating in closed-loop, select “Voltage” to charge by voltage readings.
- **System Charge SOC Limit(%):** The max. charge SOC limit for the entire system.
- **System Charge Volt Limit(V):** The max. charge Voltage limit for the entire system.
- **Charge Current Limit(A):** The max. charge current limitation of the entire system.
- **Charge Last:** This function is applicable to cases where the PV panels are over-sized. Setting charging to minimum priority allows the system to charge batteries while feeding in at maximum power when stronger PV is available, thereby maximizing the use of available solar energy.
- **SOC Hysteresis(%):** Second threshold for SOC that increases the range of charging and discharging can trigger.
- **Volt Hysteresis(V):** Second threshold for voltage that increases the range of charging and discharging can trigger.

### Discharging

- **Batt Discharge Control:** If the inverter communicates with the lithium battery and is capable of closed-loop communication, users should select “Batt. Discharge Control” according to “SOC.” When using lead-acid batteries or lithium batteries without communication, users should select discharge control according to “VOLT.”
- **Discharge Current Limit (A):** The Max. discharge current limit when grid power is on.
- **Start Discharge P\_Import(W):** Default value is 100 which means the battery will begin to discharge power to take the load when the import power from grid is higher than 100W. (Adjust range [50-100]).
- **Off-Grid Cut-Off SOC(%)/Volt(V):** When the inverter is not connected to the grid and the battery is discharging to take the load, the battery will stop discharging when the SOC/Voltage is lower than this limit.
- **On-Grid Cut-Off SOC(%)/Volt(V):** When the inverter connects to the grid and if the battery is discharging to take the load, it will stop discharge when the SOC/Voltage is lower than this limit.

## BATTERY

Battery Read

Restart Battery Module 0

Restart Battery Module 2

Restart Battery Module

- **Restart battery module:** Restarts the battery.

## MICRO-GRID

Micro-Grid

**Micro-Grid** (?) Enable Disable

**Batt Charge Current Limit(Adc)** 0Adc [0, 4000] Set

**Generator Cool-Down Time(Min)** 0Min [0.1, 25.5] Set

**Charge Start Volt(V)** (V) start: 40V 40 Set

**Charge End Volt(V)** (V) stop: 40V 40 Set

**Generator Boost** Enable Disable

**Gen Rated Power(kW)** (V) 0kW [0, 25.5] Set

**Charge Start SOC(%)** (V) start: 1% 1 Set

**Charge End SOC(%)** (V) stop: 1% 1 Set

- **Micro-Grid:** Only set this when generator is connected to the inverters grid terminal. With this enabled, the inverter will use AC power to charge the battery and will not export any power.
- **Batt Charge Current Limit(Adc):** Determines the amount of current used for charging the batteries with the generator.
- **Generator Boost:** Pulls supplemental power from both PV and battery when generator power is not sufficient to handle all loads.
- **Generator Cool-Down Time(Min):** The duration the generator continues to operate without load after the battery reaches the designated SOC or voltage stop point, prior to shut down.
- **Gen Rated Power(kW):** Limit the battery charge power based on the detected inverters load consumption and generator input power limitations.
- **Charge Start Volt(V):** Start the generator through dry contacts when battery voltage below start volt. Warming up the generator for 2 minutes before Gen relay close.
- **Charge Start SOC(%):** Start the generator through dry contacts when battery SOC below start SOC. Warming up the generator for 2 minutes before Gen relay close.
- **Charge End Volt(V):** Stop the generator by the dry contact after battery voltage is higher than end volt and perform a cool-down time.
- **Charge End SOC(%):** Stop the generator by the dry contact after battery SOC is higher than end SOC and perform a cool-down time.

## GEN FUNCTION

The screenshot shows the 'Gen Function' configuration page with three tabs: 'Generator', 'AC coupling', and 'Smart Load'. The 'Generator' tab is active. It contains two main sections: 'Generator' and 'Generator Boost'.  
**Generator Section:**  
 - Micro-Grid (?): Enable/Disable buttons.  
 - Batt Charge Current Limit(Adc) (?): Slider from 0Adc to [0, 250] with a 'Set' button.  
 - Generator Cool-Down Time(Min): Slider from 0Min to [0.1, 25.5] with a 'Set' button.  
 - Charge Start Volt(V) (?): Slider with a '40' input field and 'Set' button.  
 - Charge End Volt(V) (?): Slider with a '40' input field and 'Set' button.  
**Generator Boost Section:**  
 - Generator Boost: Enable/Disable buttons.  
 - Gen Rated Power(kW) (?): Slider from 0kW to [0, 25.5] with a 'Set' button.  
 - Charge Start SOC(%) (?): Slider with a '1' input field and 'Set' button.  
 - Charge End SOC(%) (?): Slider with a '1' input field and 'Set' button.

### Generator

- **Micro-Grid:** Should be set only when the generator is connected to the Inverter’s Grid terminal. With this option enabled, the inverter will use AC power to charge the battery and will not export any power through the Grid terminal if AC power is present at the inverter’s Grid terminal.
- **Batt Charge Current Limit(Adc):** Battery charge current limitation from Generator.
- **Generator Cool-Down Time(Min):** Set the cool-down time period for the generator before re-engaging the generator’s output to the inverter.
- **Generator Boost Enable/Disable:** Enable or disable the generator boost feature. Enable to allow the inverter to pull supplemental power from both PV and battery whenever the generator power is not sufficient to handle all loads.
- **Gen Rated Power(kW):** The battery charge power can be limited based on the detected inverter’s load consumption and Generator input power limitations.
- **Charge Start Volt(V)/SOC(%):** While using auto-start function of the generator, the “Charge Start Voltage / SOC (%)” can be limited to start up the generator automatically.
- **Charge End Volt(V)/SOC(%):** While using auto-start function of the generator, the “Charge End Voltage / SOC (%)” can be limited to turn off the generator automatically.

### AC Coupling

The screenshot shows the 'Gen Function' configuration page with three tabs: 'Generator', 'AC coupling', and 'Smart Load'. The 'AC coupling' tab is active. It contains two main sections: 'AC Couple' and 'AC Couple Start/End Volt(SOC)'.  
**AC Couple Section:**  
 - AC Couple (?): Enable/Disable buttons.  
 - AC Couple Start SOC(%) (?): Slider from start: 0% to [0] with a 'Set' button.  
 - AC Couple End SOC(%) (?): Slider from stop: 0% to [0] with a 'Set' button.  
**AC Couple Start/End Volt(SOC) Section:**  
 - AC Couple Start Volt(V) (?): Slider from start: 40V to [40] with a 'Set' button.  
 - AC Couple End Volt(V) (?): Slider from stop: 40V to [40] with a 'Set' button.

- **AC Couple Enable/Disable:** When connecting an existing on-grid system to the GEN terminal, AC Couple must be set to enable.
- **AC Couple Start Volt(V)/SOC (%):** AC Coupling will start at this set Voltage/SOC.
- **AC Couple Stop Volt(V)/SOC (%):** AC Coupling will stop at this set Voltage/SOC.

## Smart Load

- **Smart Load Enable/Disable:** When Smart load function is enabled, the GEN terminal will be reused to Smart Load, and the inverter will offer power to this load based on the setup values.
- **Grid Always On:** Once this function is enabled, smart load will always function when grid power is on.
- **Start PV Power (kW):** This is the minimum PV power limit to function with smart load output.
- **Smart Load Start SOC (%) / Volt (V):** The high limit for battery to turn on smart load.
- **Smart Load Stop SOC (%) / Volt (V):** The low limit for battery to turn off smart load.

## GRID SETTING

## Grid Connect

- **Grid Regulation:** Select the correct Grid safety regulation.
- **Grid Frequency:** If the “Grid Frequency” is nominal at 50Hz, then the inverter’s frequency will be adjusted to 50Hz automatically. If there is no grid power and it is read as 50Hz, but the devices are 60Hz, then it can be set to 60Hz manually. This is based on the rated frequency of the local grid regulation and devices.
- **Connect Time(s):** The wait time to connect to the grid if the solar input is ready and the grid power is in range of the voltage and frequency settings below.
- **Grid Volt Connect High(V):** Voltage range of Grid connect. Range [Nominal, 320]. Nominal depends on grid voltage setting, e.g. 208 or 240V.
- **Grid Freq Connect High(Hz):** Voltage range of Grid(s) connect. Range [Nominal, 320]. Nominal depends on grid voltage setting, e.g. 208 or 240V.
- **Grid Type:** Select the correct “Grid type” to function, such as split phase: 240/120 or 208/120V.
- **Permit Service:** Setting is used to enable or disable the inverter’s ability to receive remote messages from the utility or its agent. This includes starting or shutting down the inverter and completing parameter settings in accordance with regulatory requirements.
- **Reconnect Time(s):** The inverter will attempt to reconnect to the grid after abnormal situations, e.g. voltage or frequency fluctuations, once this amount of time has elapsed.
- **Grid Volt Connect Low(V):** Voltage range of Grid connect. Range [0, Nominal]. Nominal depends on grid voltage setting, e.g. 208 or 240V.
- **Grid Freq Connect Low(Hz):** Frequency range of Grid connect. Range [45, Nominal]. Nominal depends on grid frequency setting, e.g. 50 or 60Hz.

## Power Command

Grid Setting

Grid Connect Power Command

Active Power Percent(%)  [0, 100] Set

- **Active Power Percent(%)**: Set the maximum power the inverter can output, e.g. 18kPV at 100% active power percent = 12kW output. 18kPV at 50% active power percent = 6kW output.

## MANUFACTURER SETTING

Manufacturer Setting

All to Default

- **All to Default**: Sets everything back to manufacturer settings.

## DONGLE SETTING

Dongle Setting - BJ34770044 - E Wi-Fi


Server IP and Port (?)

- **Server IP and Port**: Assign the dongle server cluster or IP.

## Weekly Set

The “Weekly Set” feature makes use of several different working modes that provide users with greater control over their energy systems by allowing customized settings for each day of the week based on time of day. Prior to the release of the Weekly Set feature, users could not customize based on days of the week, leading to time-based settings repeating day after day. Now, users can configure based on time, per day, per available working mode. Working modes configurable with Weekly Set include the following: AC Charge, PV Charge Priority, Force Discharge, and Peak Shaving. Users can set up to two time periods per day, per working mode. Weekly settings will take priority over other monitor center settings which are set up outside of the Weekly Settings feature.

*Example image of the weekly settings tab using the AC Charge mode:*



Here's an example of the weekly setting feature and how it might be configured in a real-world scenario:

### AC Charge Mode:

In this example, the system operates in an area with low-cost off-peak hours. From 10:00 pm – 6:00 am each weekday customers receive extremely low cost rates from the utility. Weekends, however, do not share these discounted rates. This is a great time to take advantage of the weekly set feature to set up AC Charge mode to help keep batteries fully charged and even power loads throughout the night using cheap utility power. The end user would want to configure the Weekly Setting to apply the AC Charge working mode every weekday from 10:00 pm – 6:00 am and keep their batteries topped off. They would also set the max charge rate to 5kW.

**The following values correspond to those found in the Weekly Set section, under the AC Charge settings:**

**Working Mode Enabled:** AC Charge  
**Day(s) Selected:** Monday – Friday  
**AC Charge Power 1 (kW) Value:** 5kW  
**Stop AC Charge Volt 1(V) Value:** 54 – 56V  
**Stop AC Charge SOC 1(%) Value:** 100%  
**Time Selected:** (T1) 22:00 – 06:00

For more detailed information about the Weekly Set feature, how it is configured, and specific examples of how it may be used, please read through the EG4 Monitor Center Weekly Settings Guide, found here:

<https://eg4electronics.com/wp-content/uploads/2025/07/EG4-Monitor-Center-Weekly-Settings-Guide.pdf>

## 6.3 SET RECORD

The “Set Record” feature uses real-time information to show the end user a history of what has been done to the system, past or present.

Time	Username	Station	Serial number	Dongle	Client Type	Set Type	Set Result	Parameter Name	Parameter Value
2025-10-09 09:09:27					WEB	Normal	Success	Start AC Charge SOC(%)	4
2025-10-09 09:01:58					WEB	Normal	Success	Normal / Standby	false
2025-10-08 13:15:23					WEB	Normal	Success	Normal / Standby	true
2025-10-08 13:15:09					WEB	Normal	Success	Forced Discharge Enable	false
2025-10-08 13:14:52					WEB	Normal	Success	Start AC Charge SOC(%)	4
2025-10-08 13:14:44					WEB	Normal	Success	AC Charge Enable	true
2025-10-08 13:14:36					WEB	Normal	Success	Grid Sell Back	false
2025-10-08 13:14:29					WEB	Normal	Success	Normal / Standby	false

## 6.4 WEATHER OPTIMIZE

The “Weather Optimize” feature uses real-time weather information to adjust charging strategies based on tomorrow’s local weather conditions, ensuring the battery bank remains adequately charged. Weather Optimize reviews the weather one day at a time starting at 5 p.m. the day before. All weather data is based on the forecast from [openweathermap.org](https://openweathermap.org). For example, if heavy rain is predicted in the next day’s forecast the battery bank will be charged to the heavy rain SOC value as configured in charge percent (%) by weather area. The configuration steps are outlined below:

1. To enable Weather Optimize, the device will need to be added. To add the device, select “Add Device” (shown below). The Charge Start Time, Charge End Time and SOC values are populated with default values. All the values can be changed to the preferred time and percentages. Once the desired settings are adjusted, select “Add” to save the changes.

The screenshot shows the 'Add Device' workflow in the EG4 interface. At the top, there's a navigation bar with 'Monitor', 'Data', 'Configuration', 'Overview', and 'Maintenance'. Below it, a 'Remote Set' section has an 'Add device' button. A table lists existing devices with columns for 'Serial number', 'Station name', 'Charge Time Range', 'Location', and 'Action'. Two devices are shown, one with a green checkmark in the location column and one with a red 'X'. A modal window titled 'Add device' is open, containing fields for:
 

- \* Serial number
- \* Charge Start Time (00:30)
- \* Charge End Time (04:00)
- Charge percent(%) by weather:
  - \* Clear sky: 30
  - \* Few(11%-25%) clouds: 65
  - \* Scattered(25%-50%) clouds: 75
  - \* Broken(51%-84%) clouds: 85
  - \* Overcast(85%-100%) clouds: 95
  - \* Light rain: 80
  - \* Moderate rain: 90
  - \* Heavy rain: 100
  - \* Other: 90

 An 'Add' button is at the bottom right of this modal. Another modal window shows a map of the area around Sugar Springs, FL, with a location pin and coordinates (33.138, -95.6029). Below the map are fields for:
 

- \* Station name
- \* Create time (2023-05-15)
- \* Continent (North America)
- \* Region (North America)
- \* Country (United States of America)
- \* Timezone (GMT -6)
- \* Daylight saving time (Yes selected)

 'Update', 'Export', and 'Cancel' buttons are at the bottom of this second modal.

2. After the device is added, the location for the device needs to be set. Select the pin icon (*shown on the previous page*) and use the map, latitude and longitude coordinates, or the search option to select a location. Without a set location, there will be a red X next to the pin icon and Weather Optimize will not function. Once all location settings have been verified as correct, select the “Update” button to save the location. The red X should be changed to a green check.
3. Users can edit the Charge Start Time, Charge End Time and SOC percentages, by selecting the “Management” drop down menu and selecting “Edit” (*shown below*). Once settings are changed to the preferred values, select the yellow “Edit” button to save the changes.

The screenshot displays the EG4 web interface with the following elements:

- Navigation Bar:** Monitor, Data, Configuration, Overview, Maintenance.
- Left Sidebar:** Remote Set, Set Record, Weather Optimize (highlighted in yellow), Remote Update, Update Record, UL Compliance.
- Main Content:**
  - Buttons: Station, Add device, Search by inverter SI.
  - Table:**

Serial number	Station name	Charge Time Range	Location	Action
1		00:30 - 04:00	✓ [Pin Icon]	Management
2		00:30 - 04:00	✗	Management
  - Modal Window (Edit):**
    - \* Serial number
    - \* Charge Start Time: 00:30
    - \* Charge End Time: 04:00
    - Charge percent(%) by weather:
      - \* Clear sky: 30
      - \* Few(11%-25%) clouds: 65
      - \* Scattered(25%-50%) clouds: 75
      - \* Broken(51%-84%) clouds: 85
      - \* Overcast(85%-100%) clouds: 95
      - \* Light rain: 80
      - \* Moderate rain: 90
      - \* Heavy rain: 100
      - \* Other: 90
    - Buttons: Edit (highlighted in yellow), Cancel



**NOTE:**

Currently, the 6000XP does not support the Weather Optimization feature.

## 6.5 REMOTE UPDATE

The “Remote Update” page allows users to check and upgrade firmware on the inverters connected to the account. To check for available updates, select the blue question mark (*shown below*). If there is a suggested update the firmware version will be displayed. From the Check Updates window, selecting “Check more” will redirect to the Firmware Change log.

The screenshot displays the EG4 Remote Update interface. At the top, there are navigation tabs: Monitor, Data, Configuration, Overview, and Maintenance. Below these, there are search filters for 'Station' (Serial number) and 'Online Device'. A 'Remote Update' button is visible on the left. The main area contains a table with columns: Serial number, Dongle, Firmware version, Connect Status, and Action. The table lists several inverters, some with a blue question mark icon in the Firmware version column. A 'Check Updates' modal window is open, showing details for a specific inverter (Serial number: fAAB-1A1A, Firmware version: fAAB-1A1A) and a 'Suggestion: Standard update'. A 'Check more ->' button is highlighted in the modal. A 'Firmware Change log' window is also open, showing a list of updates and a detailed log for 'EG4\_FAAB-2525' dated 2025.09.28. The log includes details about added support for BASCO battery protocol, SunSpec Modbus IEEE-1547 certification, N-PE bonding setting, and other improvements.

## 6.6 UPDATE RECORD

The “Update Record” feature uses real-time information to show the end user a record of all updates for the system, past or present.

The screenshot displays the EG4 Update Record interface. At the top, there are navigation tabs: Monitor, Data, Configuration, Overview, and Maintenance. Below these, there are search filters for 'Select station first' and 'Server Time: 2025-10-09 16:07:22'. A 'Search by firmware file name' field and an 'Export data' button are also visible. The main area contains a table with columns: Username, Station, Timezone, Serial number, Firmware version, Mode, Firmware Type, LCD Version, Start Time, Stop Time, Rate of Progress, Firmware File, and Success. The table lists several update records, including successful updates for various firmware versions and failed updates.

## **7. CHANGELOG**

### Version 1.0.4

- Updated all images with new branding
- Updated all old branding to new branding
- Added more information about the installer and end user accounts

### Version 1.0.3

- Added additional Working Mode settings and screenshots including, but not limited to, Busbar PCS rating – Section 6.2

### Version 1.0.2

- Added Weekly Set feature under section 6

### Version 1.0.1

- Added Working Modes screenshots
- Added Working Modes descriptions
- Updated various out of date photos
- Updated various sections/language

### Version 1.0

- Published

# **EG4**

ELECTRONICS

support@eg4electronics.com  
(903) 609-1988  
www.eg4electronics.com